



YOUR CRANE IS CONNECTED. EVERY CRANE IN YOUR FLEET, VISIBLE.



Real-time data. Early alerts. Less downtime.

Ramsey Connect™ is now available on the Auto Crane **NexStar® 4**.

- Live Crane and Chassis Data
- GPS Location and Geofencing
- Text and Email Alerts



autocrane.com/ramseyconnect

Auto Crane Is Now Connected

WHY RAMSEY CONNECT™

Smart connectivity that drives **uptime, safety, and performance.**

- **Increase Uptime**

Alerts and error codes reach you by text or email, so you can handle issues before they cause downtime.

- **Reinforce Safety**

Operational visibility and intelligent alerts reinforce proper crane usage and highlight abnormal conditions.

- **Monitor Location**

Real-time GPS location services & geofencing give instant visibility across every jobsite.


WHAT YOU GET

Every crane in your fleet, visible. See crane data like boom angle, load percentage, and error codes, plus chassis data like fuel level, engine temperature, odometer, and RPM. Build custom reports, schedule them to your inbox, and set geofences and alerts.

AVAILABILITY:


- Every NexStar® 4 shipped after July 6, 2026 includes the Ramsey Connect™ gateway and 12 months of service.
- Retrofit kits are available for NexStar® 4 cranes already in the field. Ask your Auto Crane dealer.

HOW IT WORKS



Step 1

The rugged **Ramsey Connect™** gateway mounts directly to the crane and connects over a cellular network to the **Ramsey Connect™** platform.



Step 2

Your data goes to the **Ramsey Connect™** dashboard, in any web browser or the mobile app for iOS and Android, wherever the job takes you.

Connects to NexStar® 4 crane controls, chassis data, and compatible auxiliary equipment such as the Miller EnPak.

Confidence in Every Lift



Scan to watch the **full demo**, schedule a live demo, or request retrofit info.